


## Proper Clutch Adjustment: For any Mechanical Clutch



Proper clutch adjustment is vital to the life span of your clutch. A daily check for proper adjustment can make all the difference in your maintenance budget. Free play between clutch perch and lever should be 2-3mm. You can use a set of calipers to measure distance or for quick measure use a nickel (2mm) **Note: A nickel and a dime = 3mm.**

To make an adjustment undo lock nut and turn adjuster bolt counter clockwise to take out free play and the opposite to give free play. Check measurement and lock down lock nut.



If you happen to run out of adjustment at handle bar, run your adjustment nut all the way in and make adjustment at the case.